

TECHNICAL INFORMATION

KLEEN
PURGATIS

DETERGENT BOOSTER, FABRIC RINSE AND LAUNDRY ADDITIVES

PRODIL Stain Remover Salt



Art. No. 90.224.551 5 kg bucket

- **oxygen active** laundry detergent booster and fat solvent in **combination** with heavy duty detergent
- produces **stainless** white laundry and **brilliant** coloured laundry
- removing grey haze and yellowing from all white textiles
- stains originating from grass spinach, red wine, tea, coffee and cocoa will be easily removed
- **does not** contain fibre damaging substances

APPLICATION RANGE:

Laundry booster in combination with heavy duty detergents for stainless white wash and for brilliant coloured laundry. Not for use on wool and silk fabrics.

INSTRUCTIONS FOR USE AND DOSAGE:

Simply add Prodil to main wash cycle jointly with detergent. Depending on degree of soiling add between 10-20 g/kg dry laundry. Strongly soiled laundry should be presoaked prior to machine wash - in Prodil enriched water - or add Prodil into the pre-wash cycle!

Conduct a material compatibility test on a small area of the coloured laundry before starting.

Always follow the cleaning instructions of the manufacturer.

If improperly applied - and for claims resulting from such improper handling - there will be no legal claims accepted.

TECHNICAL DATA:

Form: white powder

Odour: neutral

Bulk Density: 950 g/l

pH-Value in aqueous solution: 11

INGREDIENTS:

Below 5 %: non-ionic surfactants, polycarboxylates

15-30 %: oxygen-based bleaching agents

Contains: Enzymes (lipase, protease, amylase)

Stability: at least one year in original containers

The surfactants contained in this preparation comply with the biodegradability criteria as laid down in Regulation (EC) No. 648/2004 on detergents.

LABELLING:



Warning

Hazard statements: H319: Causes serious eye irritation.

Precautionary statements: P101: If medical advice is needed, have product container or label at hand. P102: Keep out of reach of children. P264: Wash hands thoroughly after handling. P280: Wear eye protection. P305+351+338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+313: If eye irritation persists: Get medical advice.

TRANSPORT: No dangerous good in sense of these transport regulations (ADR).

KLEEN PURGATIS GmbH

Dieselstraße 10
D-32120 Hiddenhausen
Fon +49 (0) 5223 9970-40
Fax +49 (0) 5223 9970-195
info@kleen-purgatis.de
www.kleen-purgatis.de

**An Affiliated Company
of the BUDICH GROUP**

Sales Department International:

KLEEN PURGATIS International AG

Firststrasse 30A
CH-8835 Feusisberg
Fon +41 (0) 44 515 35 60
Fax +41 (0) 44 515 35 69
info@kleen-purgatis.ch

www.kleen-purgatis.com